


MODEL 21755x19D



MODEL 21755x19D

KEY NO.	DESCRIPTION	PART NO.	KEY NO.	DESCRIPTION	PART NO.
1	Engine ‡	----	43	Hub Cap - Optional	43615
2	Key, Woodruff	20062	50	Pin, Hair	31x9
3	Bolt, Engine	25x6	53	Link, Lifter	43721E701
4	Housing	70146	55	Crossbar, Front	71152E701
5	Adapter, Blade	71058	56	Clip, Retainer	71167
6	Blade	71877E701	57	Screw	26x221
7	Washer, Belleville	17x137	58	Bushing	43731
8	Washer	17x124	59	Spring, Extension	165x97
9	Bolt	1x142	60	Grip, Height Adjuster	71297
10	Push On Cap	28x42	61	Lever, Height Adjuster	71293
11	Pin, Hair	31x10	62	Crossbar, Rear	71572
12	Handle Bracket, Left	71097E701	63	Bearing, Lifter	43788
13	Handle Bracket, Right	71096E701	64	Bolt, Hex	1x91
14	Rod, Door Pivot	215x14Z	65	Support, Axle	71411
15	Screw	26x245	67	Belt, Drive	37x64
16	Deflector, Rear	43640	68	Spring	164x27
17	Door, Rear	71517	69	Transmission T/M .50	71549
18	Spring, Torsion	166x33	70	Shield, Axle	43649
19	Spacer, Door	71410	71	Retainer, Bearing	71482Z
20	Screw	26x259	72	Support, Lifter Spring	71576
21	Wheel, Front - White	43618	73	Pin, Drive	43629
22	Nut	15x84	74	Pinion, Right	71286
23	Screw	26x214	75	Pinion, Left	71287
26	Stop, Rope	42189	76	Cover, Dust	43616
27	Cover, Belt	43770E701	77	Wheel, Drive - White	43617
28	Screw	26x259	78	Washer, Thrust	17x169
29	Cover, Front Belt	71239E701	79	Screw	26x263
30	Nut, Hex Flange	15x79	80	Locknut	15x88
31	Cover, Lower	71245E701	81	Bushing	71480
32	Cover, Rear	71246E701	82	Support, Spring	71481Z
33	Screw	4x21	84	Spacer	43844
34	Nut	15x102	--	Book, Instruction	F-96520
35	Bracket, Index	71575			

‡ Parts are available from a Authorized Engine Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory.