


MODEL 40530x51C

REPAIR PARTS CHASSIS & HOOD



MODEL 40530x51C


REPAIR PARTS CHASSIS & HOOD

Key No.	Description	Part No.
1	Seat	690566
2	Cap, Push On	28x23
3	Spring	94057
4	Screw	26x229
5	Bolt, Wing	94160
6	Washer	17x47Z
7	Bolt, Shoulder	9x56
8	Support, Seat	94154E700
9	Rod, Pivot	94156 Z
10	Bracket, Pivot	94153E700
11	Bolt	1x45
12	Nut	15x89
13	Bolt, Shoulder	9x55
14	Washer	94155Z
15	Spring	164x31
16	Screw	26x249
17	Screw	26x263
18	Spring	164x30
19	Deck, Seat	94173E245
20	Nut	15x88
21	Plate, Index	94829E700
23	Mat, Left	94999
24	Mat, Right	94998
25	Hood	690608E245
26	Grille	94079E700

Key No.	Description	Part No.
27	Lens, Left	94081
28	Bezel, Left	94077Z
29	Lens, Right	94080
30	Bezel, Right	94076Z
31	Screw	26x270
32	Screw	26x238
33	Bearing, Steering	94075
34	Dash	94074E700
35	Nut	15x84
36	Panel, Access	93007E700
37	Support, Dash	95318E700
38	Bracket, Rear Hanger	94013E700
39	Support, Left Grille	94083E700
40	Axle, Hanger	94007E700
41	Support, Right Grille	94082E700
42	Bolt, Shoulder	9x51
43	Frame, Right	690206E700
44	Frame, Left	690207E700
45	Container, Battery	94069
46	Plate, Hitch	1001002E245
47	Panel, Rear	690434E245
49	Gate, Shift	94171E700
50	Cover, Shift Gate	94138E700
—	Instruction Book and Parts List	F-000762L

MODEL 40530x51C

REPAIR PARTS MOTION DRIVE



MODEL 40530x51C

REPAIR PARTS MOTION DRIVE


Key No.	Description	Part No.	Key No.	Description	Part No.
1	Rod, Adjuster	690171 Z	35	Frame, Left	690207E700
2	Link, Clutch	94183 Z	36	Screw	25x12
3	Washer	17x104	37	Frame, Right	690206E700
4	Pin, Cotter	30x20	38	Latch, Parking Brake	94045 Z
5	Spacer, Stud	94146	39	Bracket, Pedal	94035E700
6	Washer	17x47 Z	40	Lever, Clutch/Brake	94038E700
7	Grip	94198	41	Belt	37x87
8	Lever, Shift	690170 Z	42	Pulley, Idler	91179
9	Washer	17x102	43	Spacer	94132
10	Pin, Hair	31x4	44	Ring, Snap	11x7
11	Swivel	94147	45	Pulley, Drive	95094
12	Nut, Flange	15x79	46	Bracket, Left Transaxle	94008E700
13	Bracket, Shifter	690166E700	47	Spring, Extension	165x115
14	Plate, Pivot	94164E700	48	Bolt	1x155
15	Guide, Belt	93349	49	Spring, Extension	165x92
16	Spring, Extension	165x116	50	Bolt	6x105
17	Bolt, Shoulder	9x54	51	Lockwasher	17x38
18	Stud, Spring	94042 Z	52	Yoke, Shift	94031 Z
19	Bolt, Shoulder	9x39	53	Pin, Hair	31x6
20	Locknut	15x89	54	Washer	17x148
21	Arm Assembly, Idler	690173 Z	55	Spacer	91889
22	Locknut	15x84	56	Transaxle **	**
23	Screw	26x249	57	Nut, Flange	15x88
24	Bracket, Shift	94034E700	58	Key, Square	21553
25	Plate, Shift	94032E700	59	Washer	17x160
26	Nut, Adjuster	94815	60	Spacer	87x105 Z
27	Rod, Clutch	94041 Z	61	Stem, Valve	24373
28	Rod, Shift	94167 Z	62	Tire *	91414
29	Joint, Ball	21031		Tube	407049
30	Link, Shift	94172 Z	63	Wheel & Tire Assembly	92289-601
31	Locknut	15x87	64	Washer	17x195
32	Grip	91079	65	E-Ring	11x3
33	Rod, Parking Brake	94152 Z	66	Cap, Hub (Optional)	94618
34	Pedal	21544			

* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

** For information on Replacement Parts see the Central Parts Distributor in your area.

MODEL 40530x51C

**REPAIR PARTS
STEERING**




MODEL 40530x51C**REPAIR PARTS
STEERING**

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Wheel, Steering	95185	23	Washer	17x104
2	Post, Steering	690625	24	Washer	17x53 Z
3	Insert, Steering Wheel	711326	25	Nut, Flange	15x84
4	Bearing	94124	26	Axle Assembly	690210E700
5	Nut, Flange	15x111	27	Drag Link, Left	95329E700
6	Bolt, Shoulder	9x57	28	Spindle Assembly, Right	94575E700
7	Gear, Pinion	690183E700	29	Drag Link, Right	95328E700
8	Ring, Snap	11x25	30	Screw	26x249
9	Gear, Sector	94121E700	31	Bearing, Wheel	91334
10	Bearing	94123	32	Stem, Valve	24373
11	Bolt	1x84	33	Tire *	91912
12	Plate, Steering	690551E700	—	Tube	407924
13	Plate, Engine	94006E700	34	Wheel and Tire Assembly	94578–601
14	Nut, Flange	15x88	35	Washer	17x195
15	Nut, Flange	15x118	36	Washer	17x192
16	Bracket, Hanger	94013E700	37	Washer	17x113
17	Axle, Hanger	94007E700	38	Hub Cap	94618
18	Bolt	1x146	39	Screw	26x267
19	Pin, Cotter	30x49	40	Bellows	92059
20	Bearing	690150	41	Bolt	25x3
21	Spindle Assembly, Left	94576E700	42	Washer	17x146
22	Bolt	1x111			

* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

MODEL 40530x51C

**REPAIR PARTS
MOWER HOUSING SUSPENSION**




MODEL 40530x51C**REPAIR PARTS
MOWER HOUSING SUSPENSION**

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Grip	92698	22	Washer	17x168
2	Handle, PTO	94157 Z	23	Washer	17x57
3	Pad, Switch	94022 Z	24	Pin, Hair	31x4
4	Bolt	25x3	25	Washer	17x91
5	Grip	92697	26	Bolt, Carriage	2x85
6	Spring	166x40	27	Lever Assembly, Lift	690363E700
7	Washer	17x103	30	Pin	94067
8	Handle, Lift	690533	31	Bracket, Rear Suspension	94055E700
9	Lever, PTO	94017 Z	32	Spacer, Lifter	690151
10	Bolt, Shoulder	9x39	33	Bolt, Shoulder	9x53
11	Pin, Cotter	30x20	34	Bracket, Pivot	94015E700
13	Link, PTO	94004 Z	36	Washer	17x191
14	Nut, Flange	15x84	37	Nut, Flange	15x84
15	Screw	26x249	38	Spring	165x131
16	Spring	166x39	39	Nut, Flange	15x68
17	Bracket, PTO	94018E700	40	Bracket, PTO	94005E700
18	Spring	165x119	41	Hanger, Left Deck	94027E700
19	Crank, PTO	690394E700	42	Hanger, Right Deck	94026E700
20	Link, Lift	690212E700	43	Rod, Hanger	94158Z
21	Link, Lift Handle	690122E700	44	Bracket, Suspension	94058E700

MODEL 40530x51C

**REPAIR PARTS
MOWER HOUSING**



MODEL 40530x51C


REPAIR PARTS MOWER HOUSING

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Pulley, Jackshaft	92851	28	Bracket Assembly, Brake	94145E700
2	Nut, Hex	15x121	29	Spring	166x42
3	Belt, Mower Drive	37x62	30	Bracket, Suspension	94142E700
4	Pulley, Idler	690387	31	Plate	91770E700
5	Nut, Flange	15x84	32	Nut, Flange	15x88
6	Jackshaft	94129	33	Bolt, Carriage	2x53
7	Spacer	94130	34	Mandrell	92574
8	Link, Lift	690212E700	35	Bracket, Suspension	94058E700
9	Pad, Friction	94137	36	Adapter, Blade	92466
10	Bolt, Shoulder	9x52	37	Blade	92002E701
11	Bracket, Suspension	94055E700	38	Washer	17x166
12	Pad Assembly, Left Brake	94049E700	39	Washer	17x165
13	Knob	94068	40	Nut	15x100
14	Bolt, Shoulder	9x51	41	Spring	166x4
15	Plate, Suspension	94128E700	42	Cap, Push On	28x23
16	Spring	166x43	43	Rod, Pivot	94957 Z
17	Nut, Flange	15x79	44	Deflector Assembly	94707
18	Bracket, Left Suspension	94143E700	45	Bracket, Deflector	94956E700
19	Pin, Hanger	95194	46	Bracket, Front Hanger	94144E700
20	Washer	17x103	47	Washer	17x45 Z
21	Pin, Cotter	31x4	48	Guide, Belt	94781
22	Bolt	25x7	50	Bracket, Support	94681E700
23	Cover, Pulley	94051E700	51	Screw	26x249
24	Bolt, Shoulder	9x39	52	Spring, Extension	165x119
25	Arm, Idler	690408E700	53	Spacer	690369
26	Spring	166x41	54	Housing, Blade *	94888E700
27	Pad Assembly, Right Brake	94047E700	1-54	Complete Mower Housing Assembly	776103

* Includes Key No. 17, 18, 30, 31, 32, 33, 45, 46, 47 and 51.


MODEL 40530x51C

**REPAIR PARTS
ENGINE MOUNT**



MODEL 40530x51C


REPAIR PARTS ENGINE MOUNT



Key No.	Description	Part No.
1	Fuel Cap	92317
2	Fuel Tank	94073
3	Hose Clamp	95197
4	Fuel Line	23717
5	Hose Clamp	95197
6	Screw	26x201
7	Plate, Engine	94006E700
8	Throttle Control	91989
9	Engine	—
10	Bolt, Engine Mount	25x7
11	Stack Pulley Assembly	690439 Z
12	Lockwasher	19x35
13	Bolt, Hex	1x140
14	Washer	17x170
15	Screw	26x249
21	Guide, Belt	93349
22	Nut, Flange	15x79Z
23	Guide, Belt	94066
26	Screw	26x253
28	Pipe, Exhaust	92855
29	Clamp	92558
30	Shield, Heat	92550
31	Screw	26x263


MODEL 40530x51C

REPAIR PARTS ELECTRICAL SYSTEM



MODEL 40530x51C

REPAIR PARTS ELECTRICAL SYSTEM



Key No.	Description	Part No.
1	Harness, Light Wire	250x92
	Socket, Light	92372
	Bulb, Light	90084
2	Harness, Chassis Wire	250x87
3	Switch, Ignition	92556
	Key, Ignition	20729
	Nut, Hex	91489
	Cap, Ignition	91488
4	Switch, Limit	94136
5	Fuse	54212
	Holder, Fuse	407078
6	Solenoid	94613
	Screw, Mounting	26x229
	Locknut	15x116
7	Cable, Battery Ground	24x32
	Screw, Ground Cable	26x213
8	Battery	21075
	Bolt, Carriage	2x82
	Wingnut	14x79
9	Harness, Seat Switch Wire	250x67
10	Switch, Seat Sensor	94159
11	Cable	24x31