


CODE 147R 42592x11

REPAIR PARTS




NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS.
Use of service/replacement parts other than original
equipment parts may void your warranty.

ALL UNNUMBERED
ITEMS ARE INTERCHANGEABLE
WITH OPPOSITE SIDE

343593A

CODE 147R
FRONT CHASSIS ASSEMBLY

KEY #	PART #	DESCRIPTION	QTY
1	690011-853	ASM. BUMP/GRILLE	1
2	711653	SCREW, 5/16-18X1.50 HHWATAP	4
5	94455-810	GRILLE	1
6	710313	NUT, "J" TINNERMAN #C702-1420	3
7	711642	SCREW, 1/4-20X.63 HHWATAP	3
8	95234	ASM., LENS & REFLECTOR	1
8-1	94459	LENS	1
8-2	94460	REFLECTOR	1
10	710197	SCREW, 1/4-14X.50PANC	2
12	690052-810	ASM., HOOD W/STUDS	1
13	94458-810	PANEL, SIDE RH	1
14	94457-810	PANEL, SIDE LH	1
15	710184	BOLT, .497X.215HHSH 3/8-16	2
16	710067	WASHER, PLASTIC	2
17	690114	PIVOT, BASE	2
18	711622	NUT, 3/8-16 HWDFLLK MACK	2
19	690113	CAP, PIVOT	2
20	94474	QUICK RELEASE-CAM	4
21	710314	SPRING, COMP	4
22	325232	NUT, WING 1/4-20 NYLON	4
23	313674	SCREW, 1/4-20X1.25	4
26	95291-810	ASM. CONSOLE	1
26-1	95173	CONSOLE, W EXT/HOLE	1
26-2	94465	BRACKET, LH	1
26-3	94464	BRACKET, RH	1
26-4	710196	SCREW, 10-24X.500 TRSEGI	6
27	711606	SCREW, 5/16-18X.75 HHWATAP	6
32	690040	DASH	1
33	711629	SCREW, 10-24X.500 TRSEGI	2
34	711629	SCREW, 10-24X.500TRSEGI	2
35	94075	STEERING BRACKET	1
36	710197	SCREW, 1/4-14X.50 PANC	2
40	94519-810	STRUT, GRILLE	2
41	711642	SCREW, 1/4-20X.63 HHWATAP	2
42	710979	SPEED NUT	2
44	643129	LANYARD HOOD	1
45	711677	PUSHNUT, .250DIA.	1
46	711674	SCREW, 1/4-20X.63PHPNHD	2
47	710313	NUT, "J" TINNERMAN	2
48	55021	TRIM PIECE PLASTIC (2 REQUIRED)	9.50 IN.
49	55021	TRIM PIECE PLASTIC	26.80 IN.
50	93007-810	ACCESS PANEL	1
51	711629	SCREW, 10-24X.500TRSEGI	2
	711821	OWNER'S MANUAL	1



NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS.
Use of service/replacement parts other than original equipment parts may void your warranty.

ALL UNNUMBERED
ITEMS ARE INTERCHANGEABLE
WITH OPPOSITE SIDE


343693A

CODE 147R
REAR CHASSIS ASSEMBLY

KEY NO.	PART NO.	DESCRIPTION	QTY
1	94628-810	SEAT DECK, LARGE	1
2	95409	FOOTREST PAD RH	1
3	95408	FOOTREST PAD LH	1
4	94069	CONTAINER, BATTERY	1
5	711642	SCREW, 1/4-20X .63	2
6	94886	PLATE, LIFT DETENT	1
7	-	NOT USED ON THIS UNIT	
8	711629	SCREW, LIFT DETENT LOCKOUT	2
9	94154-810	SUPPORT, SEAT	1
10	95294	ZINC HINGE SEAT PIVOT	1
11	711627	NUT, PUSH CAP	2
12	710136	SPRING, COMPRESS 4.57LG X 1.17	1
13	711610	BOLT, SHOULDER 1/4-20	1
14	95293	WASHER CUP	1
15	46931	NUT, 1/4-20 WDFL LOCK	1
16	710109	SPRING, COMPRESS 2.43LG 164X30	2
17	711606	SCREW, 5/16-18X.75	2
18	95415	SEAT	1
19	711654	BOLT, SHOULDER 5/16-18	2
20	711747	BOLT, WING 5/16-18X.50	2
21	711644	WASHER, FLAT.344X .62X.06	2
22	94469	COVER, DETENT W/CUP HOLDER	1
23	309235	FASTENER, RATCHET	12
24	711671	SCREW, 1/4-15X.44/.53	3
25	94478	COVER, HAND/FOOT HYDRO	1
26	711671	SCREW, 1/4-15X.44/.53	2
27	71067	WASHER, FLAT .286X .63X.065	1
28	20107	CAP, HUB/SEAT SPRING MO#20107	2
29	71067	WASHER, FLAT .286X.63X.065	2
30	94057	SPRING-LEAF	1
31	711592	SCREW, 1/4-20X .50 WAHHTAP	2
32	94153-810	BRACKET, PIVOT SEAT	1
33	711606	SCREW, 5/16-18X.75	4
34	711634	NUT, 5/16-18 WDFLLK	4
35	314159	NUT, #10-32 CTRLK	2

CODE 147R

REPAIR PARTS



NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS.
Use of service/replacement parts other than original
equipment parts may void your warranty.

ALL UNNUMBERED
ITEMS ARE INTERCHANGEABLE
WITH OPPOSITE SIDE


343627B

CODE 147R
FRAME ASSEMBLY

KEY NO.	PART NO.	DESCRIPTION	QTY
1	95110	FRAME,RAIL RH	1
2	95111	FRAME,RAIL LH	1
3	94184	BRACKET, TRANSAXLE RH	1
4	94185	BRACKET, TRANSAXLE LH	1
5	710079	SCREW, 5/16-18X.75HHWATAP	6
6	94002	HITCH PLATE	1
7	710079	SCREW, 5/16-18X.75HHWATAP	4
8	94431	BRACKET, IDLER/TRUNNION SUPP	1
9	710079	SCREW 5/16-18X.75HHWATAP	3
10	94187	PLATE, REAR LARGE SEAT DECK	1
11	710079	SCREW, 5/16-18X.75 HHWATAP	4
12	94063	TUBE, LIFTER	1
13	94065	BUSHING, LIFT TUBE	2
14	94030	PLATE-LIFT ARM	1
15	94180	ASSY, LIFT ARM LEVER	2
16	710106	SCREW, 5/16-18X.50WHHTAP (26X49)	3
17	710310	SCREW, 5/16-24X1.25	2
18	710080	NUT, 5/16-24 NF-2 HEXFLLK	2
19	94015	BRACKET, PIVOT	1
20	710000	BOLT, .562X1.563 HSH 3/8-16	1
21	710130	FLATWASHER .406ID (17X191)	1
22	710140	NUT, 3/8-16 HWDFLK MACK 15X84	1
23	94019	CRANK, PTO (DRILLED)	1
24	94005	BRACKET, BELL CRANK	1
25	710079	SCREW, 5/16-18X.75HHWATAP	2
26	120395	FLATWASHER .469X.92X.065	1
27	94003	PLATE, STEERING MOUNTING	1
28	710079	SCREW, 5/16-18X.75HHWATAP	6
29	93349	SCREW GUIDE 5/16-18	2
30	710204	NUT, 5/16-18 HEXWEFLK WHIZ	2
31	94066	SCREW-GUIDE	2
32	710204	NUT, 5/16-18 HEXWDFLLK WHIZ	2
33	94121	SECTOR GEAR	1
34	94123	BEARING, SECTOR GEAR	1
35	710312	SCREW, 5/16-18X1.00 HHC	1
36	710105	NUT, 5/16-18 HKEPS 15X113	1
37	94632	ASSEMBLY, BRAKE LEVER	1
39	710079	SCREW, 5/16-18X.75 HHWATAP	4
40	94067	PIN, THREADED SHOULDER	2
41	45171	NUT,3/8-16HWDFLWHIZ-LOCK	2
42	94013	BRACKET, HANGER REAR	1
43	710079	SCREW, 5/16-18X.75 HHWATAP	6
45	94186	TOP, REAR PLATE LARGE SEAT DECK	1
46	710196	SCREW 10-24X.500TRSEGI	5
47	94791	YOKE ASSY-TRUNNION PEERLESS	1
48	94434	CLAMP, TRUNNION PIVOT PEERLESS	1
49	710079	SCREW, 5/16-18X.75 HHWATAP	2
50	94409	ASSY, IDLER INTERMEDIATE	1
51	710708	BOLT, 5/16-18X.5 HXFLCA	2
52	93349	ZINC SCREW GUIDE 5/16-18	1
53	710204	NUT, 5/16-18 HEXWDFLLK WHIZ	1
54	94433	TORQUE STRAP - LEFT (PEERLESS)	1
55	57072	BOLT, 5/16-18X.63 CARRLN	1
56	710205	NUT, 5/16-18 WDFLLK (15X88)	1
57	710199	SCREW. 5/16-18X.5 HXFLCA	2
58	94781	SCREW-GUIDE	1
59	710204	NUT, 5/16-18 HEXWDFLLK WHIZ PL	1

CODE 147R


REPAIR PARTS



NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS.
Use of service/replacement parts other than original
equipment parts may void your warranty.

ALL UNNUMBERED
ITEMS ARE INTERCHANGEABLE
WITH OPPOSITE SIDE


343627B

CODE 147R
FRAME ASSEMBLY


KEY NO.	PART NO.	DESCRIPTION	QTY
60	94006	PLATE, ENGINE	1
61	710079	SCREW, 5/16-18X.75 HHWATAP	4
62	710205	NUT, 5/16-18 WDFLLK (15X88)	4
64	94307	BRACKET, MUFFLER	1
65	710079	SCREW, 5/16-18X.75 HHWATAP	3
69	706	ZERK, GREASE FITTING	2
70	94203	AXLE, FRONT CAST IRON	1
71	94732	SPINDLE, RH/STD. SPIN/NO BRG.	1
72	94733	SPINDLE, LH/STD. SPIN/NO BRG.	1
73	92527	BEARING, SPINDLE	4
74	710129	WASHER, FLAT .766IDX.62ID	2
75	710103	E-RING .574IDX.050/.750 SH 11X3	2
76	710088	WASHER, FLAT .765X1.81X.059	2
77	94007	HANGER, AXLE	1
78	94026	HANGER DECK RH	1
79	94027	HANGER DECK LH	1
80	710081	SCREW 5/16-24X2.75	2
81	710080	NUT, 5/16-24 NF-2 HEXFLLK	2
82	710079	SCREW 5/16-18X.75HHWATAP	7
83	94767	ROD, DRGLNK/RH/ADJUST-5/8"	1
84	94768	ROD, DRGLNK/LH/ADJUST-5/8"	1
85	94766	TIE ROD END, 1/2-20	2
86	7058	NUT, 1/2-20 HXJAM	2
87	710440	BOLT, HHSH (9X57)	2
88	710140	NUT, 3/8-16 HWDFFLLK MACK 15X84	2
89	310364	BOLT, .500X1.18 HHSH 3/8-16	2
90	315072	WASHER, FLAT .515X1.37X.119	2
91	319618	SPACER, SLEV .515X.70X.	2
92	301188	WASHER, FLAT .378X.75X.08	2
93	780072	NUT, 3/8-16 REGHEXCTRLK	2

CODE 147R

REPAIR PARTS



NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS.
Use of service/replacement parts other than original
equipment parts may void your warranty.

ALL UNNUMBERED
ITEMS ARE INTERCHANGEABLE
WITH OPPOSITE SIDE

343368A


CODE 147R
MOTION DRIVE ASSEMBLY

KEY NO.	PART NO.	DESCRIPTION	QTY
1	*	TRANSAXLE, PEERLESS HYDRO 205-024	1
2	711669	SCREW, 5/16-18X2.50	4
3	711634	NUT, 5/16-18 WDFLLK	4
4	94429-853	BRACKET, DISCONNECT	1
5	94432-853	TORQUE STRAP	1
6	710268	SCREW, 5/16-18X.75 WAHTAP	2
7	711661	BOLT, 5/16-18X.63 CARRLN	2
8	711634	NUT, 5/16-18 WDFLLK	2
9	690013-853	ASSEMBLY, PEDAL (PEERLESS)	1
10	711688	BOLT, 5/16-18X.75 CARRSN	3
11	711633	NUT, 5/16-18 HEXWDFLLK WHIZ	3
12	95278	ROD, PEDAL LINK (PEERLESS)	1
13	711676	HAIR PIN	1
15	711594	ADJUSTING NUT 1/2-13	1
16	711682	PIN, HAIR .38DIAX1.64LG	1
17	95279	ROD HYDRO LINK (PEERLESS)	1
18	711617	WASHER, FLAT (17X91)	1
19	711614	PIN, COTTER .094DIAX.75 30X20	1
20	711676	PIN, HAIR (31X4)	1
24	95298	ROD DISCONNECT	1
25	711644	FLATWASHER .344X.62X.06	2
26	711614	PIN, COTTER .094DIAX.75 30X20	1
27	95299	ARM DISCONNECT	1
28	710346	WASHER .388/.393SQ.X1.00X.065	1
29	710657	WASHER, FLAT .256X.75X.130Z	1
30	710249	WASHER, (18X32)	1
31	710345	SCREW 1/4-28X.750HHHCNYLK	1
32	710330	SPRING, EXTENSION 2.26LG	1
33	95297	ROD, CLUTCH	1
34	711644	WASHER, FLAT .344X.62X.06	1
35	711614	PIN, COTTER .094DIAX.75 30X20	1
36	710707	SPRING, CLUTCH VST205 HYDRO	1
37	711596	NUT, ADJUSTING	1
38	690048	LATCH, PARK BRAKE	1
39	711623	WASHER, FLAT .406X.81X16GA	1
40	711614	PIN, COTTER .094DIAX.75 30X20	1
41	710333	SPRING, EXTENSION 23.10LG	1
42	710353	SPRING, TENS 3.984X.530	1
43	95108	ROD, PARKING BRAKE	1
44	95315	KNOB, PARKING BRAKE	1
45	95220	PAD, CLUTCH/BRAKE DELUX	1
46	711560	SPRING, TENSION	1
48	91179	PULLEY, IDLER 2.75	1
49	711622	NUT, 3/8-16 HWDFFLLK MACK 15X84	1
52	95305	ASM BRACKET IDLER	1
53	711613	BOLT .50X.75 HSH 3/8-16 9X39	1
54	711622	NUT, 3/8-16 HWDFFLLK MACK 15X84	1
55	91179	PULLEY, IDLER 2.75 DIA	1
56	91178	PULLEY, V-IDLER 3"	1
57	711622	NUT, 3/8-16 HWDFFLLK MACK 15X84	2
58	710531	BELT, MOTION DRIVE HYDRO 37X61	1
60	93249	PAD, TOE SANDPIPER	1
61	692300	TIRE & RIM 20X10-8	2
61-1	338524	RIM	2
61-2	338527	TIRE 20X10-8	2
61-3	338512	VALVE STEM	2
62	94618	HUB CAP	2
64	52928	KEY, SQUARE .187SQX2.25LG	2
65	711648	WASHER, FLAT .765X1.62X.065Z	4
66	95274	SPACER, .87X1.78	2
67	711758	WASHER, FLAT .765X1.81X.059	2
68	710103	RING, RETEX .57X.05TRU5133-75	2
70	94793-853	BRACKET, MOUNT HAND CONTROL	1
71	711606	SCREW 5/16-18X.75 HHWATAP	2
72	95306	ASM LEVER HAND CRUISE	1
73	711599	BOLT .375X1.59 HSH 5/16-18X.5	1
74	314944	WASHER, FRICTION FABOND NF343	2
75	335689	SPRING-COMP .875LONGX.0915 WIRE	1
76	711634	NUT, 5/16-18 WDFLLK (15X88)	1
77	690045	LINK, CRUISE CONTROL	1
78	711644	WASHER, FLAT .344X.62X.06 Z	2
79	711614	PIN, COTTER .094DIAX.75 30X20	2
82	94798	PAD, SPEED CONTROL PEDAL	1
83	94498	GRIP, HD HYD 7/16" ID	1
85	711589	WASHER, FLAT .390X1.25X.119	1
86	71072	WASHER, FLAT .406X.81X.066	1
87	711691	PUSHNUT, .240DIA. STUD	1
88	71067	WASHER, FLAT .286X.63X.065	1
90	711742	WIRE RETAINER	1
91	711606	SCREW, 5/16-18X.75 HHWATAP	1

*CONTACT YOUR NEAREST TRANSAXLE DEALER FOR PARTS AND SERVICE.


CODE 147R

REPAIR PARTS



ALL UNNUMBERED
ITEMS ARE INTERCHANGEABLE
WITH OPPOSITE SIDE


344103A

CODE 147R**STEERING ASSEMBLY**

KEY #	PART #	DESCRIPTION	QTY
9	94618	DUST HUB CAP	2
24	95185	STEERING WHEEL	1
26	94520	SHAFT, STEERING BOLT-ON	1
27	94124	BEARING-LOWER	1
28	711606	SCREW, 5/16-18X.75	2
29	94122	GEAR PINNION	1
30	710102	RING, RET E	1
31	692639	TIRE&RIM, 15X6.0X6	2
31-1	338512	VALVE STEM	2
31-2	338517	RIM	2
31-3	338513	BEARING	2
31-4	338515	TIRE 15X6X6	2
32	94618	HUBCAP, AXLE SHAFT	2
33	-	NOT USED ON THIS UNIT	
34	711758	WASHER, FLAT .765X1.81X.059	2
35	710103	E-RING .574IDX.050/.750SH 11X3	2
42	711326	INSERT, 4-SPOKE	1
43	711719	SCREW, 1/4-20X .75	1
44	711663	WASHER, FLAT .281X1.25X.06	1

CODE 147R


REPAIR PARTS



NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS.
Use of service/replacement parts other than original
equipment parts may void your warranty.

ALL UNNUMBERED
ITEMS ARE INTERCHANGEABLE
WITH OPPOSITE SIDE


343695A

CODE 147R**MOWER SUSPENSION ASSEMBLY**

KEY NO.	PART NO.	DESCRIPTION	QTY
1	711676	PIN, HAIR	1
8	94611-853	LINK, LIFT LH	1
9	94053-853	LINK, LIFT RH	1
10	711617	WASHER, FLAT	2
11	711676	PIN, HAIR	2
13	711617	WASHER, FLAT	2
14	711676	PIN, HAIR	2
19	95285	LINK LIFT HANDLE	1
20	711617	WASHER, FLAT	1
21	711676	PIN, HAIR	1
22	94497	GRIP, LIFT	1
23	95296	HANDLE, LIFT	1
24	711616	WASHER, FLAT.550X1.00X11	1
25	710111	TORSION SPRING .657LG (166X40)	1
26	94496	GRIP, PTO 5/8"	1
27	690126	PTO HANDLE	1
28	95284	ZINC PADDLE, SWITCH	1
29	711621	SCREW, THD FORM.246X1.050LG	2
30	94018-853	BRACKET, PTO	1
31	780055	SCREW, 5/16-18X.50	2
32	95283	ZINC LEVER, PTO	1
33	711613	BOLT.50X.75HHSH3/8-16	1
34	711659	PIN, HAIR .072 DIA X1.13LG	2
35	711615	WASHER, FLAT.518X.87X16	2
36	95282	LINK PTO	1
37	711622	NUT, 3/8-16	1
38	711606	SCREW, 5/16-18X.75	1
39	710141	TORSION SPRING .33LG (166X39)	1
40	710311	SPRING, TENSION	1
41	710208	EXTENSION SPRING (165X119)	1

CODE 147R


REPAIR PARTS



NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS.
Use of service/replacement parts other than original
equipment parts may void your warranty.

ALL UNNUMBERED
ITEMS ARE INTERCHANGEABLE
WITH OPPOSITE SIDE


343592A

CODE 147R
ENGINE & CONTROL ASSEMBLY


KEY PART NO.	PART NO.	DESCRIPTION	QTY
1	ENGINE	19HP INTEK	1
2	710199	SCREW, 3/8-16X1.25 WAHHSPTAPP	4
3	711689	DECAL, ENGINE 19HP	1
4	94655	MUFFLER, TWIN CYCLINDER	1
5	95204	TUBE, EXHAUST	1
6	711852	SCREW, (B/S #94755)	4
8	711851	B/S EXHAUST GASKET (B/S #273485)	2
9	711606	SCREW, 5/16-18X.75 HHWATAP	2
18	711642	SCREW, 1/4-20X.63 HHWATAP	4
19	93077	SPACER, SLEV 1.015IDX1.77OD	1
24	95259	PULLEY, STACK ASSY	1
25	120383	WASHER, REGSPTLK .459X.78X.12	1
26	710248	SCREW, 7/16-20NF1.50	1
27	94484	FUEL TANK W/SENSOR 2.8 GAL	1
28	711681	SCREW, 15TPIX	4
29	95250-853	HEATSHIELD	1
30	50118	TUBING, GAS LINE	14 IN.
32	47345	CLAMP, HOSE SCREW TYPE	2
34	92317	FUEL CAP	1
35	325547	OIL DRAIN VALVE ASSEMBLY	1
36	327422	CAP, OIL DRAIN VALVE ASM.	1
38	94501	THROTTLE CONTROL	1
39	711686	SCREW, #8-16X.50 TRCRTAPAB	2
46	711601	NUT, 1/4-20 REGHXJAM	1
50	710247	WASHER, FLAT .480X1.00X.25	1
51	95325	PLENUM, HOOD MOUNT	1
52	690043	CHOKE CONTROL	1
53	314522	CLIP, CHOKE CONTROL	2
54	711677	PUSHNUT, .250DIA.	4
56	711742	RETAINER, .31IDX.62X.03 WIRE	1
57	711592	SCREW, 1/4-20X.50 WAHHTAP	2

CODE 147R


REPAIR PARTS



NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS.
Use of service/replacement parts other than original
equipment parts may void your warranty .

ALL UNNUMBERED
ITEMS ARE INTERCHANGEABLE
WITH OPPOSITE SIDE


344108A

CODE 147R**PRE-PAINTED DECK ASSEMBLY**

KEY NO.	PART NO.	DESCRIPTION	QTY
1	710144	BRACKET, DECK RH	1
3	94192	BRACKET, DECK LH	1
4	57072	BOLT, 5/16-18X.63 CARR.	5
5	710204	NUT, 5/16-18 HEXWDFLLK WHIZ	5
9	92426	TOE GUARD, FLANGE	2
10	57072	BOLT, 5/16-18X.63 CARR.	2
11	710205	NUT, 5/16-18 WDFLLK (15X88)	2
12	710143	ASSY, FRONT BRACKET ROLLER	1
13	57072	BOLT, 5/16-18X.63 CARR.	4
14	710204	NUT, 5/16-18 HEXWDFLLK WHIZ	4

CODE 147R

REPAIR PARTS



NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS.
Use of service/replacement parts other than original
equipment parts may void your warranty.

ALL UNNUMBERED
ITEMS ARE INTERCHANGEABLE
WITH OPPOSITE SIDE


344102A

CODE 147R
DECK ASSEMBLY

KEY NO.	PART NO.	DESCRIPTION	QTY
1	344108-853	ASSY 42" MOWER DECK DELUXE	1
12	710199	SCREW, 3/8-16X1.25 WAHHSPTAPP	10
13	94051-853	COVER, SEGMENT BELT GUIDE	4
14	690138-853	ASM., BRACKET SUP W/BRAKES 42"	1
14-1	94193	BRACKET, BRAKE MT	1
14-2	94047	ASSY, BRAKE RH	1
14-3	94049	ASSY, BRAKE LH	1
14-4	710227	TORSION SPRING (166X41)	2
14-5	710098	BOLT .50X.75 HHSH 3/8-16 (9X39)	2
14-6	710140	NUT, 3/8-16 HWDFLK MACK (15X84)	3
14-7	94781	SCREW GUIDE	1
14-8	690137	ASS'Y, IDLER ARM	1
14-9	710205	NUT, 5/8-16HWDFLK	1
17	690073	TUBE, BRAKE TAB PAD (2 REQUIRED)	0.450
18	91801	PULLEY, IDLER BFF 4.75DIA.	1
19	711622	NUT, 3/8-16HWDFLK MACK 15X84	1
20	341594-853	ASM.PLATE, REAR SUS.BRKT.LH	1
20-1	94128	PLATE - SUSPENSION	1
20-2	94055	SUSPENSION BRKT REAR	1
20-3	710095	BOLT, SHOULDER 3/8-16 (9X52)	1
20-4	710140	NUT, 3/8-16 HWDFLK MACK 15X84	1
22	341593-853	ASM.PLATE, REAR SUS.BRKT.RH	2
22-1	94128	PLATE - SUSPENSION	1
22-2	94055	SUSPENSION BRKT REAR	1
22-3	710095	BOLT, SHOULDER 3/8-16 (9X52)	1
22-4	710140	NUT, 3/8-16HWDFLK MACK 15X84	1
23	711611	BOLT, SHOULDER .375 (9X51)	2
24	710113	SPRING, TORSION .68LG LH 166X43	1
25	710112	SPRING, TORSION .68LG RH 166X42	1
26	711622	NUT, 3/8-16HWDFLK MACK 15X84	2
27	711600	WINGNUT 5/16-18	2
28	94137	PAD, FRICTION	2
29	711628	WASHER, (17X45)	2
36	711595	PIN, HANGER	2
37	711622	NUT, 3/8-16 HWDFLK MACK	2
39	94687	CHUTE DEFLECTOR	1
40	95303	ROD, CHUTE DEFLECTOR	1
41	710194	SPRING, TORSION .44X2.06X	1
42	711627	NUT, PUSH CAP .375 (28X23)	2
43	690058-853	ASSY., BRACKET & STIFFENER	1
43-1	94058	BRACKET, FRT SUSPENSION	1
43-2	95057	STIFFENER	1
43-3	710079	SCREW, 5/16-18X.75 HHWATAP	4
44	711611	BOLT, SHOULDER .375 (9X51)	2
45	711622	NUT, 3/8-16 HWDFLK MACK	2
65	310071	ROLLER, 6 X.515 I.D.X 2.5 O.D.	1
66	95275	ROD, SUPPORT	1
67	711667	PIN, COTTER .125 DIA X 1.00LG	1
71	95295	ROD, HANGER	1
72	711676	HAIR PIN	1
73	64686-853	DEFLECTOR SUPPORT	1
74	711624	RIVET - SEMI .244X.250 (7X125)	2
85	711617	WASHER, FLAT	1
86	30289	WAVE WASHER	1
90	94956-853	BRACKET, CHUTE ATTACH	1
91	711661	BOLT, 5/16-18X.63 CARR.	2
92	711634	NUT, 5/16-18 WDFLLK	2

CODE 147R

REPAIR PARTS



NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS.
Use of service/replacement parts other than original
equipment parts may void your warranty.

ALL UNNUMBERED
ITEMS ARE INTERCHANGEABLE
WITH OPPOSITE SIDE


344102A

CODE 147R
DECK ASSEMBLY

KEY NO.	PART NO.	DESCRIPTION	QTY
2	92574	ASM., JACKSHAFT HOUSING 42"	2
3	95308	PULLEY, 42" INPUT	2
4	94129	JACKSHAFT 7.12LG	2
5	94130	SPACER, .625X.875X1.858	2
6	710191	NUT, 9/16-18 UNF-2B (15X121)	2
7	92466	ADAPTER, DECK/BLADE	2
8	95100	42" (3N1) BLADE	2
9	710118	WASHER, FLAT .625X1.75 17X166	2
10	710117	WASHER, FLAT .625X1.00X.188	2
11	710104	NUT, 9/16 REGHEX (15X100)	2
21	710213	BELT, 42" DECK (37X88)	1
46	92683	GAUGE WHEEL, 4.94DIA.	2
47	711746	BOLT, SPSH 3/8-16X.63	2
48	711622	NUT, 3/8-16 HWDFLK MACK	2
49	711615	WASHER, FLAT .518X.87X16	2
55	711797	PIN, LYNCH	2
60	94669-853	GUARD, BELT RH	1
61	94668-853	GUARD, BELT LH	1
62	711642	SCREW, 1/4-20C.63HHWATAP	4
68	95080-853	COVER, DISCHARGE MULCH	1
69	711651	BOLT, 5/16-18X.75 CARR.	2
70	711604	NUT, WING 5/16-18 SERR	2
76	318197	PAD, ADHESIVE	1
80	92265	WHEEL, GAUGE	2
81	711657	BOLT, .5X3.27 HHSH 3/8-16	2
82	95188	SPACER, SLEV. NYLON .515X1.00X.70	2
83	41529	NUT, 3/8-16 CTRLK JAM	2
84	95187-853	ROD, GAUGE SHORT	2

CODE 147R

REPAIR PARTS



343371B

CODE 147R

ELECTRICAL ASSEMBLY

KEY NO.	PART NO.	DESCRIPTION	QTY
1	95202	WIRE HARNESS	1
2	711579	WIRE, LEAD SOLENOID TO STARTER	1
3	340530	WIRE HARNESS, REAR	1
4	340513	WIRE HARNESS, HEADLIGHT	1
5	780216	BULB, HEADLIGHT 1156	2
6	57444	TIE, CABLE BLACK NYLON 5.62L	5
7	55939	WIRE CLIP ADHESIVE	1
8	94762	SWITCH, IGNITION DELTA 7 TERM	1
9	327350	KEY, IGNITION DELTA	1
11	92372	SOCKET, LAMP	2
12	94136	SWITCH LIMIT DELTA	2
13	94613	SOLENOID	1
14	711619	SCREW, HHWATAP 1/4X.50	2
15	711632	NUT, 1/4-20 HEXNYL 15X116	2
16	710228	WIRE, GROUND 24X32	1
17	711619	SCREW, HHWATAP 1/4X.50	1
18	94159	SWITCH, SEAT	1
19	302257	BATTERY 12V 7 PLATE	1
20	711680	BOLT, 1/4-20X.63 CARR.	2
21	711636	NUT, WING 1/4-20 NC (14X79)	2
22	94522	DIAGNOSTIC PACKAGE	1
24	711376	NUT, PLASTIC THUMB 3/8-27	1
	302031	FUSE, 15 AMP	

SCHEMATIC WIRING

